

ADD-A-BIKE ASSEMBLING INSTRUCTIONS



BEFORE USING THE ADD-A-BIKE CLAMP, PLEASE FOLLOW THESE ASSEMBLING INSTRUCTIONS CAREFULLY.

1. Insert T-bolt as shown in Fig. 1.
2. Rotate bolt 90 degrees and snap into pegs (on bottom of clamp) securely. See Fig. 2 & 3.
3. Follow mounting instructions on back of the carton.

